



## How to measure for your Allusion Blinds:

**Please always measure to the nearest 5mm increment**

**Example:**

**1000mm, 1255mm, 1485mm, 1600mm, 1845mm, 2235mm etc**

There are two ways to install/measure you Allusions:

- Top Fix - fitted from your ceiling
  - Outside reveal (on wall - overlapping the window)
- with Allusion Blinds its always best to measure 500mm past your window/door so you have stacking space and clear view of your outside area.

**Allusion Blinds**

*Overlapping Door Only*

- Measure the width of the door first in millimeters,
- Measure the top section as you see in image,
- Add anything from 300mm to 600mm (it is your choice) to your width size.
- Measure the height,
- Measure the middle part of the window
- Deduct 10mm off the height (we deduct 10mm off the height so the fabric does not touch the floor
- Submit the sizes on the Order Page

*Ceiling Top Fix fitting:*

- Measure the width and then the height - deduct 10mm from the width and height for fitting space.

Example:

**Slight over lapping measurement: 2500 x 2200 (ADDED 500MM TO WIDTH & 100MM TO HEIGHT)**

**Ceiling Top Fix measurement - 4390 x 2390 (DEDUCTED 10MM FROM WIDTH AND HEIGHT FOR FULL WALL FITTING)**

