



How to measure for your blinds:

Please always measure to the nearest 5mm increment

Example:

1000mm, 1255mm, 1485mm, 1600mm, 1845mm, 2235mm etc

There are two ways to install/measure you blind:

- Inside reveal (inside the window)
 - Outside reveal (outside window - overlapping the window)
- we recommend to add 100mm extra on your inside reveal, this means that your blind will overlap 50mm on each side width and height.

25mm / 35mm / 50mm Aluminium & Wooden/Plastic Wooden Venetian Blinds

Inside reveal measurement:

- Measure the width first in millimeters,
- Measure the top, middle and bottom section as you see in image
- Write down the smallest measurement and deduct 10mm (we deduct 10mm so the blind has spacing on the sides, no touching walls.)
- Measure the height
- Measure the middle part of the window (no need to deduct anything)
- Submit the sizes on the Order Page

Outside reveal measurement:

- Take the inside measurement size and add 100mm to width and height

Example:

Inside measurement: 1465 x 1250

Outside measurement: 1575 x 1350

