



## How to measure for your blinds:

**Please always measure to the nearest 5mm increment**

**Example:**

**1000mm, 1255mm, 1485mm, 1600mm, 1845mm, 2235mm etc**

There are two ways to install/measure you blind:

- Inside reveal (inside the window)
  - Outside reveal (outside window - overlapping the window)
- we recommend to add 100mm extra on your inside reveal, this means that your blind will overlap 50mm on each side width and height.

### **Double Roller Blinds**

*Inside reveal measurement:*

- Measure the width first in millimeters,
- Measure the top section as you see in image,
- Deduct 10mm off the width (we deduct 10mm off the width so the Vision Blind cassette can fit perfectly and does not touch the side walls)
- Measure the height,
- Measure the middle part of the window
- Deduct 10mm off the height (we deduct 10mm off the height so the material does not touch the window sill)
- Submit the sizes on the Order Page

*Outside reveal measurement:*

- Take the inside measurement size and add 100mm to width and height

Example:

**Inside measurement: 1465 x 1240**

**Outside measurement: 1575 x 1350**

