



How to measure for your blinds:

Please always measure to the nearest 5mm increment

Example:

1000mm, 1255mm, 1485mm, 1600mm, 1845mm, 2235mm etc

There are two ways to install/measure you blind:

- Inside reveal (inside the window)
 - Outside reveal (outside window - overlapping the window)
- we recommend to add 300mm extra on your inside reveal, this means

that your blind will overlap 150mm on each side width - the height we split 200mm to top and 100mm at bottom.

Outdoor Roller Sheerweave

Inside reveal measurement:

- Measure the width first in millimeters,
- Measure the top section as you see in image
- Measure the height,
- Measure the middle part of the window

---Deduct 10mm from your width only---

- Submit the sizes on the Order Page

Outside reveal measurement:

- Take the inside measurement size and add 300mm to width and height

Example:

Inside measurement: 2990 x 2200

Outside measurement: 3300 x 2500

