



How to measure for your blinds:

Please always measure to the nearest 5mm increment

Example:

1000mm, 1255mm, 1485mm, 1600mm, 1845mm, 2235mm etc

There are two ways to install/measure you blind:

- Inside reveal (inside the window)
 - Outside reveal (outside window - overlapping the window)
- we recommend to add 100mm extra on your inside reveal, this means that your blind will overlap 50mm on each side width and height.

Vision Blinds

Inside reveal measurement:

- Measure the width first in millimeters,
- Measure the top section as you see in image,
- Deduct 10mm off the width (we deduct 10mm off the width so the Vision Blind cassette can fit perfectly and does not touch the side walls)
- Measure the height,
- Measure the middle part of the window
- Deduct 10mm off the height (we deduct 10mm off the height so the material does not touch the window sil)
- Submit the sizes on the Order Page

Outside reveal measurement:

- Take the inside measurement size and add 100mm to width and height

Example:

Inside measurement: 1465 x 1240

Outside measurement: 1575 x 1350

